

Below are tips to help maintain a safe working environment when using your Keurig® Single-Serve Coffee Maker:



When Cleaning...

- **Wash hands thoroughly** with soap and water for at least 20 seconds and/or use **antibacterial hand sanitizer**.
- **Wear clean gloves and wipe down/disinfect all brewer buttons, the K-Cup® pod holder, and any external surfaces that you will touch to operate the coffee maker.**



Cleaning Instructions:

Cleaning of all external surfaces of your **Keurig®** Single-Serve Coffee Maker, including the K-Cup® pod holder should be done on a regular basis.

- **If surfaces are dirty, they should be cleaned prior to disinfection using** a mild detergent or antibacterial soap and water.
- **We recommend regularly disinfecting all brewer buttons, K-Cup® pod holder and any external surfaces that users touch to operate the coffee maker.**
- For disinfection, **most common EPA-registered household or commercial disinfectants should be effective.**
Spray disinfectant on a clean cloth and use it on the coffee maker.
- **Allow the equipment to air-dry once disinfected.**



Reminder:

- **Remove K-Cup® pod when brewing is complete.**

